

## User manual for Dinasys acoustic information system

1. Place the earpiece on your ear
2. The metal surface of the earpiece should touch the skin behind your ear, so kindly move any obstructions, such as your hair. If you wear glasses, it is not a problem as the arm of the earpiece will fit underneath the arm of your glasses.
3. Attach the little box, which is attached to the earpiece, to your clothes using the clip. Alternatively, you can also let it hang down. Do not hold the box in your hand, as this may affect the volume and reduce your audio experience..
4. You may leave the earpiece on the whole time. There are two positions: 1) is tight on the ear and 2) is approximately 1 cm from your ear.
5. You will simply switch on the earpiece by taking out the connector. We do recommend to switch the earpiece on only while you are listening and to then put the connector back again.
6. Unfortunately, there is currently no possibility to change the volume on the earpiece.
7. The transmitter is placed under the aluminium plate with Braille lettering on the rear side of the wooden information stands. Simply touch and hold on the Braille plate to receive the message. If you stop touching the plate for more than 3 seconds, the message will be disconnected. To listen to the information messages in English, simply touch the Braille plate twice in 1 second intervals.

### Warning: Choking hazard

The earpiece contains small parts that may potentially become a choking hazard. Therefore, we do not recommend parents to allow children under age of 6 years to use the earpiece.